



Triple Bowl Plumbing Kit

Easy to assemble Attachment for an appliance BPP-PK3 KTM-PK-001



5056077913540

Made in China

BPP-PK3

- 3 x Long pipe (1) 3 x Curved pipe (2) 1 1 x Mid section (3) 1 x Ubend section (4) 1 x Short curved section (5) 10 x Connector (A) 10 x Seals (B) 1 x Appliance connector (C) 1 x Stopper (D) 1 x Seal (E) 1 x Connector (F) 1 x Connector (G) 1 x Seal (already attached to part 5) (H) 1 x Stopper (I) 1 x Seal (J) AB BAAB IJ
- 1. Place one part A and one part B on the straight end of part 1.
- 2. Now connect to part 2 as per the diagram, at the bottom end of part 2 place one part A and one part B and attach. Repeat for all three sides.
- 3. Connect part 2 to part 3. At the bottom of part 3 again place one part A and one part B.
- 4. Connect part 3 to part 4, Take one part A and one part B and attach to part 5.
- 5. Make sure part H is in part 5 take part E and part F and attach to existing pipe work.
- 6. For the appliance connector, part C, connect this to either side of part 3 using part D as required see diagram.

